


Want to clean the drawer or interior organisation system? No problem! InnoTech drawer system



Drawer removal



Front panel disassembly

- Drawer removal: open all the way, push in plastic release buttons in the runner, pull diagonally towards you
- Drawer installation: place on the runners, push in straight, guide closed
- Front panel disassembly: remove cover cap, press blue release buttons, pull front panel up and off
- Front panel assembly: fit into the drawer front connectors from above, firmly press into place
- Products for cleaning drawers and interior organisation systems:
 - Use a soft, non-linting cloth and a water-soluble, mild cleaning agent, such as liquid or neutral soap – recommended as best in the product information for your kitchen furniture
 - Do not use any abrasive cleaners/sponge scourers, paint thinners or irritant/corrosive chemicals as they may damage the surfaces over the long term
 - In general, stains should be removed as quickly as possible to prevent them from working into the surfaces



Plastic interior organisation systems: Dishwasher safe

